



**Wykaz konstrukcji wsporczych ładowaczy.**

L.p.	Marka ciągnika	Model ciągnika	Pasujący typ ładowacza
1	<b>Belarus/MTZ</b>	82, 82.1, 820, 820.1, 820.2, 820.3,	Ł-107 A, Ł-104 A, Ł-105, Ł-106A, Ł-108
2		892, 892.1, 892.2, 892.3	Ł-107 A, Ł-104 A, Ł-105, Ł-106A, Ł-108
3		920, 920.1, 920.2, 952, 952.1, 952.2	Ł-107 A, Ł-104 A, Ł-105, Ł-106A, Ł-108
4		920.3, 920.4, 952.3, 952.4,	Ł-104A, Ł-106 A, Ł-108
5		1025, 1025.1, 1025.2, 1025.3, 1025.4	Ł-104A, Ł-106 A, Ł-108
6		1221, 1221.1, 1221.2, 1221.3, 1221.4	Ł-108
7	<b>Case</b>	<b>Farmall A</b> : 65A, 75 A	Ł-107 A, Ł-104 A, Ł-105
8		<b>Farmall A</b> : 85 A, 95 A, 105 A, 115 A	Ł-104 A, Ł-105, Ł-106 A, Ł-108
9		<b>JX</b> : 60, 70	Ł-107 A, Ł-104 A, Ł-105
10		<b>JX</b> : 80, 90, 95	Ł-104 A, Ł-105, Ł-106 A
11		<b>JXU</b> : 1070, 1080, 1090, 1100, 75, 85, 95, 105, 115	Ł-105, Ł-104 A, Ł-106 A, Ł-108
12		<b>Maxxum</b> : 100, 110	Ł-106 A, Ł-108
13		<b>Maxxum</b> : 115, 125, 140	Ł-108
14		<b>MX</b> : 100, 110, 120, 135	Ł-108
15	<b>Deutz Fahr</b>	<b>Agrolux</b> : 65, 75 (wersja z kabiną oraz bez kabiny)	Ł-107 A, Ł-104 A, Ł-105
16		<b>Agrolux</b> : 410 (wersja z kabiną Naglak oraz bez kabiny)	Ł-107 A, Ł-104 A, Ł-105
17		<b>Agroplus</b> : 310, 315 , 320	Ł-107 A, Ł-104 A, Ł-105
18		<b>Agroplus</b> : 410, 420	Ł-107 A, Ł-104 A, Ł-105
19		<b>Agroplus Ecoline</b> : 310 , 315, 320	Ł-107 A, Ł-104 A, Ł-105
20		<b>Agrofarm</b> : 410 DT, 85 DT	Ł-104 A, Ł-105, Ł-106 A
21		<b>Agrofarm</b> : 420 DT, 430 DT, 100 DT	Ł-106 A, Ł-108
22		<b>Agrofarm G</b> : 410 , 430	Ł-106 A, Ł-108
23		<b>Agrotron K</b> : 410, 420, 100	Ł-106 A, Ł-108
24		<b>Agrotron K</b> : 610, 110	Ł-108
25		<b>Agrotron M</b> : 600, 610 ,615, 620	Ł-108
26		<b>5C</b> :5090C, 5100C, 5110C,5120C,	Ł-106 A, Ł-108
27		<b>5G HD</b> : 5090.4, 5105.4	Ł-106 A, Ł-108
28		<b>5G MD</b> : 5090.4, 5105.4	Ł-106 A, Ł-108
29	<b>Farmer</b>	8244 C2	Ł-107 A, Ł-104 A, Ł-105
30		665, 665DT, 70 2WD, 70 4WD,	Ł-107 A, Ł-104 A, Ł-105
31		<b>Heritage</b> : 6050DT, 6060DT, 6075DT	Ł-107 A, Ł-104 A, Ł-105
32		670, 670DT,	Ł-107 A, Ł-104 A, Ł-105
33		675 DT KING, 675DT, 675, 80 2WD, 80 4WD,	Ł-107 A, Ł-104 A, Ł-105
34		FT 670 DT IIIB, FT 675 DT IIIB	Ł-107 A, Ł-104 A, Ł-105
35		685DT , 690DT	Ł-107 A, Ł-104 A, Ł-105
36		685DT IIIB, 690DT IIIB	Ł-107 A, Ł-104 A, Ł-105
37		7100DT, 7110DT,	Ł-106 A, Ł-108
38		7100DT IIIB, 7110DT IIIB	Ł-106 A, Ł-108
39	<b>Foton</b>	604, 704	Ł-107 A, Ł-104 A, Ł-105
40		824, 904	Ł-107 A, Ł-104 A, Ł-105, Ł-106 A
41	<b>John Deere</b>	<b>M</b> : 5070 , 5080 , 5090 , 5100 (made in Germany)	Ł-104 A, Ł-105
42		<b>R</b> : 5080 , 5090 , 5100 ,	Ł-105, Ł-106 A
43		<b>5E</b> : 5055 , 5065 , 5075	Ł-107 A, Ł-104 A, Ł-105
44		<b>5E</b> : 5083 , 5093	Ł-107 A, Ł-104 A, Ł-105
45		<b>5M</b> : 5085, 5100, 5115 (made in USA)	Ł-106 A, Ł-108
46		<b>6D</b> : 6100, 6115, 6130	Ł-106 A, Ł-108
47		<b>6M</b> : 6115, 6125	Ł-106 A, Ł-108
48		<b>6 MC</b> : 6090 , 6100 , 6110 <b>6 RC</b> : 6090 , 6100 , 6110	Ł-106 A, Ł-108
49		<b>6030</b> : 6130, 6230, 6330, 6430	Ł-106 A, Ł-108
50		<b>6030</b> : 6530, 6630, 6830, 6930	Ł-108

Producent ładowaczy czołowych do wszystkich typów ciągników rolniczych  
[www.agromasz.com.pl](http://www.agromasz.com.pl), [agromasz@o2.pl](mailto:agromasz@o2.pl)



ZAKŁAD METALOWY „AGROMASZ”  
ul. Lubelska 42B 11-700 Mragowo  
tel. fax (089) 741-21-92 NIP 742-000-20-67

51		6020, 6120, 6220, 6320, 6420	Ł-106 A, Ł-108
52		6520, 6620, 6920	Ł-108
53		5620, 5720, 5820	Ł-104A, Ł-105, Ł-106 A
54	Kubota	M : 6060, 7060, 6040, 7040	Ł-107 A, Ł-104 A, Ł-105
55		M : 8560, 9960, 8540, 9540	Ł-105, Ł-106A
56		M : 105 S, 108 S	Ł-105, Ł-106A
57		M : 110 GX	Ł-105, Ł-106 A, Ł-108
58		M : 135 GXS	Ł-106 A, Ł-108
59		Me : 8200, 9000	Ł-104 A, Ł-105, Ł-106 A
60	Lamborghini	Grand Prix : 90 DT, 95	Ł-105
61		Nitro R: 90,100,110, 120	Ł-106 A, Ł-108
62		R2: 60, 80	Ł-105
63		R2 Target: 56, 66	Ł-105
64		R2 Target: 76,86	Ł-105
65		R3 EVO: 85, 100, 110	Ł-105, Ł-106 A
66		R3: 90,100	106 A, Ł-108
67		R6:100, 110	Ł-106 A, Ł-108
68		R6: 130, 140	Ł-106 A, Ł-108
69		Strike HD: 90.4, 105.4	Ł-106 A, Ł-108
70	Strike MD: 90.4, 105.4	Ł-106 A, Ł-108	
71	Landi ni	Powerfarm: 60, 75	Ł-105
72		Technofarm: 70, 80	Ł-105
73		5H: 080, 090, 100, 110	Ł-105, Ł-106A
74		Vision: 85, 95,105	Ł-105, Ł-106A
75		Powerfarm: 80DT, 85DT, 90DT, 95DT, 100DT,105DT	Ł-105, Ł-106A
76	Massey Ferguson	4445, 4455	Ł-105
77		3060, 3065	Ł-107 A, Ł-104 A, Ł-105
78		3070	Ł-107 A, Ł-104 A, Ł-105
79		6140	Ł-104 A, Ł-105, Ł-106 A
80		5460	Ł-106 A, Ł-108
81	McCormick	CL : 65, 75 , 70, 80	Ł-105
82		CXL: 65, 75, 85	Ł-105
83		CXL : 70, 80	Ł-105
84		CMax: 60, 75	Ł-107 A, Ł-104 A, Ł-105
85		CMax: 80, 85, 90, 95, 105	Ł-105, Ł-106A
86		CMax: 100, 110	Ł-105, Ł-106 A
87		CX: 90, 95, 100, 105	Ł-105, Ł-106A
88		Cx: 110	Ł-106 A, Ł-108
89		GMax: 125, 135	Ł-106 A, Ł-108
90		GMax: 145, 165	Ł-108
91		GMax E: 145, 165	Ł-108
92		MC : 115	Ł-105, Ł-106A, Ł-108
93		MC : 120, 135	Ł-108
94		MTX Beta Power: 120, 135, 150	Ł-108
95		X4: 4.50, 4.60, 4.70	Ł-104 A, Ł-105
96		X 60: 60.20, 60.30, 60.40, 60.50	Ł-106 A, Ł-108
97	New Holland	T : 4020, 4030, 4040, 4050	Ł-107 A, Ł-104 A, Ł-105
98		T : 5030, 5040,5050, 5060, 5070	Ł-105, Ł-106 A, Ł-108
99		T: 6010, 6020 (Delta / Plus)	Ł-106 A, Ł-108
100		T : 6030, 6050	Ł-106 A, Ł-108
101		T : 6030, 6050,6070 Plus	Ł-106 A, Ł-108
102		TD : 60, 70 (D i D PLUS)	Ł-107 A, Ł-104 A, Ł-105
103		TD: 80 ,85, 90, 95 (D i D PLUS)	Ł-105
104		TD : 5010, 5020	Ł-107 A, Ł-104 A, Ł-105
105		TD : 5030, 5040, 5050	Ł-105, Ł-106 A
106		TD 5.: 65,75	Ł-107 A, Ł-104 A, Ł-105
107	TD 5.: 85, 95, 105, 115 Tier IVA (oraz Tier IVB)	Ł-105, Ł-106 A,	

Producent ładowaczy czołowych do wszystkich typów ciągników rolniczych  
[www.agromasz.com.pl](http://www.agromasz.com.pl), [agromasz@o2.pl](mailto:agromasz@o2.pl)



ZAKŁAD METALOWY „AGROMASZ”  
ul. Lubelska 42B 11-700 Mrągowo  
tel. fax (089) 741-21-92 NIP 742-000-20-67

108		<b>TL</b> : 80, 90, 100	Ł-105
109		<b>TL A</b> : 80 A, 90 A, 100 A	Ł-106 A, Ł-108
110		<b>TM</b> : 120, 125, 140	Ł-108
111		<b>T4</b> :75, 85, 95,105 (HiLo)	Ł-104 A, Ł-105
112		<b>T4. Power Star Tier 4A</b> : 75, 85, 95	Ł-107 A, Ł-104 A, Ł-105
113		<b>T4. Power Star Tier 4B</b> :55, 65, 75	Ł-107 A, Ł-104 A, Ł-105
114		<b>T5</b> :T5.95, T5.105,T5.115	Ł-106 A, Ł-108
115		<b>T6</b> .: T6.120,T6.140,T6.150,T6.160	Ł-106 A, Ł-108
116		<b>T6</b> .: 155, 165, 175 <b>Delta</b> ,	Ł-108
117		<b>T7</b> .: 170, 185, 200,210 (także wersja z oryginalnym TUZ-em)	Ł-108
118		70-56 <b>BIS</b>	Ł-105
119	<b>Pronar</b>	82	Ł-107 A, Ł-104 A, Ł-105, Ł-106A, Ł-108
120		82A, 82 SA, 82 TSA, (most przedni Carraro)	Ł-104 A, Ł-106 A, Ł-108
121		1025A	Ł-104A, Ł-106 A, Ł-108
122		1221A	Ł-108
123	<b>Pol-Mot</b>	<b>H</b> : 8014 , 9014, 10014	Ł-104 A, Ł-105, Ł-106 A, Ł-108
124	<b>Same</b>	<b>Dorado</b> : 56, 66, 60, 80	Ł-105
125		<b>Dorado</b> : 76, 86	Ł-105
126		<b>Explorer</b> : 95	Ł-106
127		<b>Explorer</b> : 90 <b>Top II</b>	Ł-106
128		<b>Explorer HD DT LS</b> : 90.4, 105.4,	Ł-106 A
129		<b>Explorer MD DT LS</b> :90.4, 105.4,	Ł-106 A
130		<b>Explorer<sup>3</sup></b> : 90, 105	Ł-106 A
131		<b>Explorer<sup>3</sup></b> : 85 DT, 100 DT, 110 DT	Ł-105, Ł-106 A, Ł-108
132		<b>Roller</b> : 55 W, 60, 70D, 70 W	Ł-105
133		<b>Tiger</b> : 65,75,	Ł-105
134	<b>Virtus J</b> : 90,100,110,120	Ł-106 A, Ł-108	
135	<b>Steyer</b>	<b>Kompakt</b> : 4085,4095,4105	Ł-105, Ł-106 A, Ł-108
136	<b>TYM</b>	<b>T</b> : 903, 1003	Ł-105, Ł-106 A, Ł-108
137	<b>Ursus</b>	C-385, 902, 904, 912, 914, 932, 934, 1012, 1014, 1032, 1034, 1044, 1132, 1134	Ł-105, Ł-106 A, Ł-108
138		<b>H</b> : 8014, 9014, 10014	Ł-105, Ł-106 A, Ł-108
139		5024, 4512, 4514, 5312, 5314, 5714, 6012, 6014	Ł-104 A, Ł-105,
140		5524, 6824	Ł-105, Ł-106 A, Ł-108
141		7524,	Ł-105, Ł-106 A, Ł-108
142	<b>Zetor</b>	<b>Forterra</b> :100, 95, 105, 115, 8641, 9641, 10641, 11441	Ł-106 A, Ł-108
143		<b>Major</b> 80,	Ł-107 A, Ł-104 A, Ł-105
144		<b>Proxima</b> (90, 100, 85, 95, 8421, 8441),	Ł-106
145		<b>Proxima</b> (65, 70, 75, 80 ,6421, 6441,7421,7441),	Ł-107 A, Ł-104 A, Ł-105
146		<b>Proxima</b> (90,100,110) <b>Plus</b>	Ł-106
147		<b>Proxima</b> (90,100,110, 120) <b>Power</b>	Ł-106
148		5211, 5245, ,	Ł-105
149		4320, 4340, 5320, 5340,6320,6340,7320, 7340	Ł-105
150		5341 , 7341	Ł-105
151		6245,7011, 7045,7211,7245,7711,7745	Ł-107 A, Ł-104 A, Ł-105
152		8011, 8045, 8111, 8145, 8245, 1011, 10045, 1014	Ł-106
153		8540, 9540, 10540	Ł-106 A, Ł-108
154		12111, 12145, 16145, 16245 <b>ZTS</b>	Ł-108